

V65U UNIVERSAL SPILL KIT



(A) Universal Absorbent Socks

Uses: Use on hazardous or unknown liquid spills. Absorbs all liquids including water.



(B) Universal Absorbent Pads

Uses: Use on hazardous or unknown liquid spills. Absorbs all liquids including water.



(C) 10 oz. Jar of Plug 'N Dike Repair Putty

Uses: Temporarily plugs or slows punctures.



(D) Splash Goggles

Uses: Protects eyes from harmful agents when cleaning up a spill.



(E) Nitrile Splash Gloves

Uses: Protects hands from harmful agents when cleaning up a spill.



(F) Hazardous Materials Disposal Bag

Uses: Place all contaminated materials into the bag for safe disposal. Call Environment Canada or Safety Office for correct disposal procedures.



(G) Polyethylene Drain Cover

Uses: Prevents spill from entering drain.



(H) 3 lb. Bag of Granular Clean Up Absorbent, Universal

Uses: Place on the spill for final clean up.

**To Reorder Call
(403) 253-7299**





SPILL PROCEDURE

INSTRUCTIONS

1. EMPTY CONTENTS OF KIT ON THE GROUND NEAR THE RELEASE/SPILL. PUT ON SAFETY EQUIPMENT.
2. IF LIQUIDS ARE MIGRATING TOWARDS DRAIN USE POLY DRAIN COVER ALONG WITH SOIL OR SNOW (TO WEIGHT DOWN EDGES).
3. IF TANK OR DRUM IS LEAKING REFER TO "PLUG N' DIKE" INSTRUCTIONS AND SEAL UP THE LEAK OR SLOW IT DOWN.
4. ENCIRCLE SPILL WITH SOCKS.
5. TOSS PADS IN THE CENTER OF THE SPILL, AND RETRIEVE IF SATURATED.
6. RETRIEVE PADS AND SOCKS, AND PLACE IN DISPOSABLE BAG
7. CALL ENVIRONMENTAL OR SAFETY OFFICER FOR CORRECT DISPOSAL PROCEDURES.

PLUG N' DIKE REPAIR

PROCEDURE

1. PACK A BALL OF PLUG N' DIKE INTO PUNCTURE.
2. TURN, ¼ TURN APPLYING CONSTANT PRESSURE.
3. SMOOTH OVER EDGES WITH EXTRA WATER.
4. IF ON FOR EXTENDED PERIODS OF TIME, KEEP MOIST WITH WATER, OR SMEAR SOME GREASE OVER THE REPAIR TO PREVENT DRYING.

(NOTE: THIS IS NOT A PERMANENT SOLUTION, DO NOT USE AS SUCH)

(Without prejudice no liability)



V-65-U **VEHICLE UNIVERSAL SPILL KIT**

18" Long x 15" wide x 5" Thick
Contained in a Refillable, Zippered Bag
For Easy Behind-The -Seat Storage

Contains:

- 3 – Universal Absorbent Socks 3" x 48"**
- 10 – Universal Absorbent Pads 3/8" x 17" x 19"**
- 1 – 10oz. Jar of Plug N' Dike Repair Putty**
- 1 - Hazardous Materials Disposal Bag, 36" x 48" x 5mil.**
- 1 – Polyethylene Drain Cover (48" x 48")**
- 1 – 3lb. Bag of Granular Final Clean up absorbent, Universal**
- 1 - Pair Splash Goggles, indirect-vent**
- 1 - Pair Nitrile Splash Gloves, flock lined**
- 1 - List of Contents**

For Refills, and replacement kits, please call.....

Calgary 403-253-PAXX (7299)
Toll free 1-866-389-PAXX (7299)
www.paxxindustrial.com